

# WHITE ENAMEL FOR ELECTRICAL APPLIANCES

Indoor - Outdoor. Gloss



Product Code: S03

## Description

High quality acrylic enamel. Quick-drying. For repairing scratches and small damage on enamelled surfaces, such as heaters, refrigerators, kitchen and bathroom appliances.

## Fields of Application

Because of its excellent resistance to outdoor conditions, it can also be used for repairing and painting garden furniture, metallic tables and chairs, when a gloss white finish is required.

## Technical Data

<b>Product Type</b>	Acrylic copolymer
<b>Finish</b>	Gloss
<b>Colour (UNE EN ISO 11664-4)</b>	White
<b>Coverage</b>	200 ml spray can: 0.2 - 0.4 m <sup>2</sup> , 400 ml spray can: 0.4 - 0.8 m <sup>2</sup>
<b>Drying at 23°C 60 % RH (UNE 48301)</b>	5 minutes (dust dry)
<b>Recoat time at 23°C 60% RH (UNE 48283)</b>	30 minutes
<b>Application Temperature, RH&lt;80%</b>	+10°C - +30°C
<b>Pack sizes</b>	200 ml and 400 ml

Variations in temperature, humidity, thickness, tinting or surface type, etc. may lead to changes in drying, in coverage or in other properties.

## Directions for use

### GENERAL REMARKS:

Shake the spray can for one minutes while hearing mixing balls. The surfaces to be painted have to be clean, dry and sound. Protect the surfaces that are not to be painted. Perform a test spray on a non-visible area. Apply crossed thin coats at a distance of 25 to 30 cm. Spray two thin coats instead of one thick coat. In this way, a better protection and a smooth, gloss finish will be achieved.

Let to dry for 48 hours before setting it in contact in water.

Not recommended for large damage in bathtubs and wahbasins.

### BARE SURFACES:

Previously apply a base coat of Spray White Rust-Preventive Primer in order to ensure a good adhesion of the enamel coat. Apply the Spray White Enamel for Electrical Appliances once the primer is dry.

In order to mask colours contrast with the original paint, it is advisable to thoroughly coat the whole primed area and even exceed its outline.

### MAINTENANCE OF PREVIOUSLY COATED SURFACES IN GOOD CONDITION:

Remove dust, grease or dirt and directly apply Spray Enamel for Electrical Appliances

### MAINTENANCE OF PREVIOUSLY COATED SURFACES IN POOR CONDITION:

Remove all poorly adhered materials, smooth up the surface by sanding and, once clean, rust-free and dry, proceed as for bare surfaces.

## Precautions

Always read the pack label before use. For more information, please refer to the Safety Data Sheet.

Store in tightly closed containers protected from sources of heat and temperatures below 0°C. Shelf life: 36 months in original unopened packaging.

**Waste management:** Follow local legal regulations. Help to protect the environment, do not empty into drains, dispose of this material and its container at hazardous or special waste collection points. Calculate the amount of product you will need to avoid waste and extra costs. Collect the leftover material and keep it well stored for a new use.

Issue date: 2018-08

Any technical sheet is automatically cancelled by a subsequent sheet or five years after the issue date. We guarantee the quality of our products. However, we disclaim any liability in relation to factors other than the coating itself or in relation to an unsuitable use or application method. In case of doubt, please refer to our technical service before applying the products.



Akzo Nobel Coatings, S.L.U – Carrer Feixa Llarga, 14-20 - Pol. Ind. Zona Franca 08040 Barcelona  
(España)  
Teléfono 934 842 500  
Ins. Reg. Mer. de Barcelona T. 47631, F- 95, H. nº B-45052, Inscrp. 210  
N.I.F. B-08218158

